



## 2. PARTS DESCRIPTION


### 2.1 BOX CONTENT



### 2.2 INDOOR UNIT (MONITOR)




### 2.3 OUTDOOR UNIT (DOORBELL)




## 3. INSTALLATION


### 3.1 FIX THE MOUNTING PLATE OF THE INDOOR UNIT (MONITOR)




### 3.2 FIX THE MOUNTING PLATE OF THE OUTDOOR UNIT (DOORBELL)




### 3.3 ELECTRICAL INSTALLATION




### 3.3.1 CONNECTING THE TERMINAL BLOCKS (INDOOR AND OUTDOOR UNIT)




3.3.2 MOUNT THE INDOOR UNITS AND OUTDOOR UNIT




3.3.3 CONNECTING AN ADDITIONAL MONITOR (NOT INCLUDED)




3.3.4 CONNECTING THE AC POWER




3.3.5 CONNECTING A DOOR LOCK (NOT INCLUDED) | 3.3.6 CONNECTING A GATE OPENER (NOT INCLUDED)



4. REPLACE CALL BUTTON



5. BASIC FUNCTIONS



6. HOME SCREEN AND MENUS

