

THANKS FOR YOUR PURCHASE!

Before using, please read the instruction and safety precautions carefully. Please keep the instruction where you can find it easily. Failure to comply with these operating instructions can cause damage to the product, the environment, people and animals. The operating instructions are based on the standards and rules applicable in the European Union. When abroad, also observe country-specific guidelines and laws. Operating Instructions has to be kept since it contains important information. If you pass the product on to third parties, be sure to pass these operating instructions, too.

Let's be friends! Follow us on instagram



@LIFE_OF_EGGY_EGG

PACKAGE CONTENT



1x SWIMMY HIPPO



1x Manual



1x DC-USB
cable

INSTRUCTION




SWITCH: HIPPO needs a petting to switch on. When petting, HIPPO surprises with a random play of light colors.

HIPPO shines particularly beautifully in a dimmed environment.

TURN OFF: The light will go out automatically if you do not touch it for 5 minutes

CHARGING: If the bath light is weak, it needs to be charged. Only charge the bath light when the charging socket is dry! Use the supplied USB cable and stuck the jack plug on the underside of the bath light into the intended socket. Connect the USB plug to a USB adapter. The charging control on the side shows the charging process and goes out when full charged.



PRODUCT PARAMETERS

Product name	SWIMMY HIPPO
Product model	87403 ML
Brand	MegaLight
Specifications	107x71x68 mm
Materials	ABS, PC, Silicone
Light color	RGB
Light power	0,1W
Battery capacity	Akku 3.7V 200mAh
Lighting duration	25h
Charging Time	1.5h
Protection Degree	IP67
Protection class	III

PLEASE NOTE



Attention:

Intended use The product is only intended for private use and is not suitable for commercial use. Use the product only as described in these operating instructions. Any other use is considered improper and can lead to property damage. The manufacturer or dealer assumes no liability for damage caused by improper or incorrect use.

Safety instructions The lamp is designed as a bath light. The light-ball may not be disassembled. The bath light is only appropriate for normal bath water. Do not let your child play in the water unsupervised. The product must not be dismantled or burned. The product's light source is not replaceable. If the light source is no longer functional, the entire lamp must be disposed of properly. Do not expose the product to extreme temperatures. Don't put it in direct sunlight. Do not heat the lamp with external means. A repair is not possible, the lamp must be disposed of if it is defective. If the battery is defective or leaked, the product must be disposed of immediately. Periodically inspect the USB-C-cable for external damage that is suspected of causing a fire, electric shock, or injury. If you suspect such a hazard, do not use the product and contact the manufacturer. Only charge the night light out of the reach of your child. To charge the SWIMMY HIPPO, connect the cable to a suitable power source: USB charging adapter (at least 1000mA). Only charge the night light out of the reach of your child. There is a risk of

strangulation with the charging cable, so keep it out of the reach of your child.

Do not charge the bath light near water. Warning. Long cable. Strangulation hazard. Do not let your children play with the packaging or packaging accessories; keep them out of your child's reach.

The transformer, power supply or battery charger used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.



WARNING! CHOKING HAZARD. Small parts. Not for children under 3 years. Keep the address of the company.



Separate supply unit



Follow the instructions in the operating instructions.



This toy is only to be connected to equipment bearing either of the following symbols.

Cleaning To clean, turn off the lamp on the underside, empty the water that has run in and let the bath light dry. The lamp can then be reinserted and tightened. Please clean the bath light regularly for hygienic reasons. Use only neutral cleaning agents and no sharp-edged cleaning accessories. Warning: Do not clean the bath light while it is charging.

DISPOSAL



packaging

Dispose of the packaging according to type of material.

Dispose of cardboard and cardboard as waste paper and foils in the recyclable waste collection.



Waste Equipment

(Applicable in the European Union and other European countries with systems for the separate collection of recyclable materials)

- Electrical and Electronic Equipment must not be disposed of with household waste!

- If the product can no longer be used, every consumer is legally obliged to separate Electrical and Electronic Equipment from household waste, e.g. at a collection point in his community / district. This ensures that old equipment is properly recycled and negative effects on the environment are avoided. That is why electrical devices are marked with the symbol shown here.

- Batteries und rechargeable batteries are not household waste
- As a consumer, you are legally obliged to dispose of all batteries and accumulators, regardless of whether they contain harmful substances or not, at a collection point in your community / district or in the shop so that they can be disposed and recycled towards an environmentally friendly manner.
- Attention! This product contains batteries that are non-replaceable.