



LEDLENSER HF6R


HF6R Core




HF6R Work




HF6R Signature




Magnetic Charge System




Battery Indicator




Low Battery Warning




Transportation Lock




Boost




Boost Overheat Warning




Lamp Head Rotation




Connecting System Adapter (HF6R Work/HF6R Signature)




Comfort Pad





Wall Holder (HF6R Work)



Digital Advanced Focus System




Helmet Adapter (HF6R Work)




Ledlenser GmbH & Co. KG
 Kronenstrasse 5-7 • 42699 Solingen • Germany
 Phone +49 212/5948-0 Fax +49 212/5948-200
 info@ledlenser.com




HF6R Core/HF6R Work




HF6R Signature



Direct to Red Mode (HF6R Core/HF6R Work)



Direct to RGB Mode (HF6R Signature)



HF6R Core/HF6R Work

